



Adventure F5J Sport

www.adventure-rc.com

adventurekind@gmail.com

Recommended equipment and adjustments

1. Spinner: 32 mm ~15 gr.
2. Blades: 15x8", Freudenthaler, GM Prop... ~ 18 gr.
3. Engine: PowerLine 1015, Leomotion L3007-5000 F5J, AXI 2217/12... ~ 100 gr.
4. Speed controller: Hacker X40SB, YGE-35LTV... ~ 45 gr.
5. Servos:
 - KST X10, Graupner DES-448... 2x ~22 gr.
 - KST X08 2x ~10 gr.
 - KST X06, KM-04MD... 2x ~5 gr.
6. Battery: 3S, 800-1800 mAh 80-160 gr.
7. For a start Center of gravity is needed to be placed 82-83 mm backward from leading edge of inboard wing panel . Moving CG back leads to the rise of sensitivity .
8. Fuselage and tail boom are not needed to glue: combine signs and wrap a few layers of adhesive tape.